FROST

MOUNTING INSTRUCTIONS - RADA SHOE RACK

W5001-B	W5002-B
W5001-W	W5002-W
W5001-CB	W5002-CB
W5001-CW	W5002-CW
W5001-GB	W5002-GB
W5001-GW	W5002-GW




Material: Stainless steel, polished + steel, powder coated.

Design: busk+hertzog

Dimensions:

W5001 Height: 120 mm Width: 600 mm Projection: 164 mm Weight: 3 kg W5002 Height: 120 mm Width: 1000 mm Projection: 164 mm Weight: 5 kg



Mounting instructions:

Hold the mounting plate in horizontal position against the wall and mark the pre-drilled holes with a pencil. After drilling, insert the supplied dowels and fix the plate with screws. Next, hang up the shoe rack by pushing it sideways into the centre of the mounting plate. If necessary, use a rubber hammer to tamp it carefully into the correct position.

