


SOAP DISPENSER 3050, FREE STANDING

DESIGNED BY BØNNELYCKE MDD

PRODUCT DETAILS, TECHNICAL DETAILS AND FITTING INSTRUCTIONS



MATERIAL: STAINLESS STEEL **AVAILABLE IN THE NINE FROST FINISHES:**























ALL MEASUREMENTS ARE IN MILLIMETERS WWW.FROSTDENMARK.COM


(RE)FILLING SOAP

Gently pull the top upwards to remove the soap container from the dispenser body.

Unscrew the soap container from the top part. Fill the container with liquid soap.

Screw the container back onto the top part and push the assembled top and container back into the dispenser body until its in place.

Note: please use a PH-neutral liquid soap to ensure the longevity of the soap dispenser.



CARE INSTRUCTIONS


If the dispenser is not used for a long period of time and becomes clogged, pour warm water into the soap container and gently pump it to clear the blockage.

All surfaces should be cleaned with a microfiber cloth, glass cleaner or other non-abrasive and gentle agents. If stained, clean with warm soapy water. Use a soft cloth to wipe dry. Soap and cleaning agents must be regularly removed from stainless steel surfaces in order to prevent corrosion-like residues.

Never try inserting a sharp object e.g. pin into the soap nozzle. This can irreparably damage the pump and void the warranty.

Never use solvents or aggressive household cleaners like bleach, acids (e.g. descalers) or ammonia-based bathroom cleaner to clean the product.

Should brown deposits appear around the lid or pump, remove with soapy water and a soft brush. Hard deposits can be scratched off with your fingernail. In order to avoid this, try changing to a liquid soap with a neutral PH.



ALL MEASUREMENTS ARE IN MILLIMETERS WWW.FROSTDENMARK.COM

CLEANING AND MAINTENANCE

Surfaces should be cleaned with a microfiber cloth, glass cleaner or other non abrasive and gentle agents.

ATTENTION:

Never use solvents or aggressive household cleaners like bleach, acids (e.g. descalers) or ammonia-based bathroom cleaner to clean the product. Steel wool and hard brushes can permanently damage the surface of the steel.

EXCLUSION OF LIABILITY

FROST accepts no liability whatsoever for damage to persons or property that occurs or has occurred as a result of improper installation or maintenance, particularly if the safety instructions and other points to note listed are not or have not been observed in full.

WARNING AND HAZARD NOTICES

Improper mounting or use can lead to accidents and serious injuries.

www.frostdenmark.com

Bavne Alle 32, 8370 Hadsten, Denmark E-mail: info@frost.dk • Phone: (+45) 87 61 00 32

We are also to be found as frostdenmark on Facebook, Instagram, Pinterest and LinkedIn





